

# DIGIPRINT TRANSFER-PAPIER

## DIGIPRINT TRANSFER PAPER

### **ANWENDUNG:**

Spezialpapier zur Übertragung von Druckbildern auf weisse oder hellfarbene Baumwollfaser-Textilien mit einer Presse oder einem Bügeleisen.

### **DRUCK:**

Der Druck ab Indigo E-Print Pro+ oder Turbostream sollte spiegelverkehrt auf die *glatte* Papierseite erfolgen.

### **WEITERVERARBEITUNG:**

Das zu übertragende Sujet wird mit einem freien Rand von etwa 5 mm ausgeschnitten und mit der bedruckten Seite auf das faltenfreie Textil gelegt.

### **ÜBERTRAGUNG:**

Mit **Heisspressen** bei 160°C und ca. 40 Sekunden, Papier heiss bzw. noch warm abziehen.

Mit **Bügeleisen** (auf höchste Temperaturstufe aufheizen, keinen Dampf benutzen) für mindestens für 2 Minuten über die Papierrückseite bügeln. Es sollten alle Ränder von der Mitte des Bügeleisens erfasst werden, damit die Übertragung auch an den Bildkanten vollständig ist. Nach dem **Erkalten** des Papiers kann dieses von einer Ecke aus unter stetigem Zug leicht abgezogen werden, das Bild verbleibt auf dem Textil.

### **WASCHEN:**

Waschen Sie bei **max. 40°C**, die bedruckte Seite nach innen gekehrt. Keine Bleichmittel. Keinen Tumbler verwenden. Bügeln nach dem Waschen: Schützen Sie das Bild mit Papier (vorzugsweise Backpapier).

### **APPLICATION:**

Special paper for heat-transfer (heat press/iron-on) of printed images onto white, or light coloured cotton textiles.

### **PRINT:**

Print the mirror image on the non grid *smooth* paper side with an HP Indigo press.

### **PREPARATION:**

Cut out the image to be transferred with a 5 mm margin and put it face down on the smoothed out fabric.

### **TRANSFER:**

With **heat presses** at 160°C and appr. 40 seconds, remove paper while still hot resp. warm.

With **iron** (use highest temperature setting and no steam) for at least 2 minutes with steady pressure.

Be sure to cover all edges of the cut out image with the centre of the iron to ensure complete transfer.

Let the paper cool and remove the **cold** paper by peeling it from one corner. The image remains on the textile.

### **WASHING:**

Wash at **max. 40°C**, turning the garment inside out. Do not bleach. Do not use a tumble-dryer. Ironing after washing: Protect the image with paper (preferably kitchen baking paper).